

Most hooking ball ever!!!
 Aggressive midlane with continuation
 Higher intermediate differential for stronger motion
 Raising the bar on overall hook


Choose the layout for the desired ball motion and tune the surface.

Cash Drilling Suggestions

	Layout Specs	Low RG	Int Diff	Total Diff	RG PAP
	Undrilled	2.504	0.020	0.048	
A	Length with Maximum Hit 50 x 4 1/2" x 40 (P3 hole)		0.042	0.065	2.543
B	Length with Control 70 x 5" x 75		0.027	0.050	2.535
C	Maximum Flare 65 x 4" x 30 (Double Thumb hole)		0.050	0.075	2.527
D	Less Hook with Big Hit 90 x 2 1/4" x 50 (P1 hole)		0.024	0.040	2.540

RADICALBOWLING.COM


Length with Maximum Hit



A

Layout:
50 x 4 1/2" x 40
with P3 Hole

Length with Control




B

Layout:
70 x 5" x 75

Axis point used for these layouts is 5" over by 3/8" up.
The dotted line shows the axis migration path of the drilled ball.


Maximum Flare



Layout:
65 x 4" x 30
with Double Thumb Hole

C

Less Hook with Big Hit




Layout:
90 x 2 1/4" x 50
with P1 Hole

D

Axis point used for these layouts is 5" over by 3/8" up.
The dotted line shows the axis migration path of the drilled ball.

Balance Holes for Asymmetrical Layouts: *If, and when, a balance hole is needed, we recommend using the “Gradient Line Balance Hole System”. The Gradient Line extends from the PSA to P1 passing through the PAP.*



Balance Hole Locations on the Gradient Line

Balance hole Position	Location	Change in Ball Reaction
P1	6 ¾" from the PSA on the VAL	Weakens ball reaction
P2	1/3 of the distance from the P1 to the PSA	Maintains ball reaction
P3	2/3 of the distance from the P1 to the PSA	Strengthens ball reaction
P4	PSA	Maximizes ball reaction

Ball Surface & Cleaning: ***RADICAL** bowling balls are manufactured with a predetermined surface preparation. With the assistance of a qualified pro shop, sanding, scuffing, or smoothing the surface texture may be needed to optimize performance for different styles of players on different lane conditions. We cannot overemphasize the importance of regularly cleaning your **RADICAL** ball with a quality bowling ball cleaner IMMEDIATELY AFTER each use. Doing so will insure a more consistent reaction and maximize the life of your **RADICAL** bowling ball.*

Determining the Bowler's Initial Axis Tilt: *Initial Axis Tilt is best determined by measuring the distance across the bowler's initial ball track on the surface of the ball. A measurement of > 11 1/4" (< 12 degrees) indicates a high track bowler. A measurement of 10 1/4" to 11 1/4" (12 to 18 degrees) indicates a medium track bowler. A measurement of < 10 1/4" (> 18 degrees) indicates a low track bowler.*